modulair BLUE

Heating via UFH & Duct

	Description
A	Modul-AIR BLUE
B	Modul-AIR BLUE Site Unit
C	Underfloor Heating
D	ComfortZone Thermostat
E	Ventilation Silencer
F	Motorized Damper
G	Potable Expansion Vessel
H	Inlet Control Group
I	Mains/Boosted Cold Inlet
J	Balanced Cold Outlet



modulair BLUE

Cooling via UFH & Duct

	Description
A	Modul-AIR BLUE
B	Modul-AIR BLUE Site Unit
C	Underfloor Heating
D	ComfortZone Thermostat
E	Ventilation Silencer
F	Motorized Damper
G	Potable Expansion Vessel
H	Inlet Control Group
I	Mains/Boosted Cold Inlet
J	Balanced Cold Outlet



modulair BLUE

Heating via UFH / Duct

	Description
A	Modul-AIR BLUE
B	Modul-AIR BLUE Site Unit
C	Underfloor Heating
D	ComfortZone Thermostat
E	Ventilation Silencer
F	Motorized Damper
G	Potable Expansion Vessel
H	Inlet Control Group
I	Mains/Boosted Cold Inlet
J	Balanced Cold Outlet
K	Fan Coil



modulair BLUE

Cooling via Fan Coil / Duct

	Description
A	Modul-AIR BLUE
B	Modul-AIR BLUE Site Unit
C	Underfloor Heating
D	ComfortZone Thermostat
E	Ventilation Silencer
F	Motorized Damper
G	Potable Expansion Vessel
H	Inlet Control Group
I	Mains/Boosted Cold Inlet
J	Balanced Cold Outlet
K	Fan Coil



modulair BLUE

Heating via Fan Coil

	Description
A	Modul-AIR BLUE
B	Fan Coil
C	Ventilation Silencer
D	Motorized Damper
E	Potable Expansion Vessel
F	Inlet Control Group
G	Mains/Boosted Cold Inlet
H	Balanced Cold Outlet



modulair BLUE

Heating via Fan Coil

	Description
A	Modul-AIR BLUE
B	Fan Coil
C	Ventilation Silencer
D	Motorized Damper
E	Potable Expansion Vessel
F	Inlet Control Group
G	Mains/Boosted Cold Inlet
H	Balanced Cold Outlet